


# Caution: Fixture length cannot be modified in the field. Consult factory for custom lengths.

### 50 239 - installation:

- 1. Unscrew steel cable griplock to separate canopy cover from canopy moutning plate.
- 2. Feed driver wires through canopy mounting plate.
- 3. Make supply wiring and driver wiring connections inside the wiring box (by others):
  - MAIN VOLTAGE SUPPLY WIRE TO BLACK LUMINAIRE WIRE NEUTRAL (COMMON) SUPPLY WIRE TO WHITE LUMINAIRE WIRE GREEN GROUND WIRE TO GREEN LUMINAIRE WIRE

### Dimming (if applicable):

- DIMMING CONTROL WIRE (+) TO POSITIVE DIM CONTROL WIRE DIMMING CONTROL WIRE (-) TO NEGATIVE DIM CONTROL WIRE
- 4. Mount canopy baseplate directly to standard recessed 4" octagonal wiring box (by others).
- 5. Nove canopy cover up to the ceiling/canopy mounting plate and tighten steel cable griplock to secure.



## Relamping/Maintenance

50.8W LED

36.3W LED

19.4W LED

Lamp:

Unscrew glass by turning counter-clockwise. Clean glass and luminaire using on solvent-free cleansers. Replace glass.

**Opal Glass** 

Downlight

Uplight

Accessories
Please refer to the appropriate
accessory installation sheet for
further instruction when applicable.

# Replacement PartsDescriptionParts

#### Part No

### **Opal Glass**

LED driver (120-277V) Consult Factory LED module (3000K) (x4) LED-0660/830 LED module (4000K) (x4) LED-0660/840

### Downlight

LED driver (120-277V) Consult Factory LED module (3000K) LED-0624/830 LED module (4000K) LED-0624/840

### Uplight

LED driver (120-277V) Consult Factory LED module (3000K) (x2) LED-0660/830 LED module (4000K) (x2) LED-0660/840

In the interest of product improvement, BEGA reserves the right to make technical changes without notice.

Product Safety Warnings: THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. SUITABLE FOR DAMP LOCATIONS. MIN 90°C SUPPLY CONDUCTORS

MIN 90°C SUPPLY CONDUCTORS.

CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS. CONVIENT AUX EMPLACEMENTS HUMIDES.

LES FILS D'ALIMENTATION 90°C MIN.